

REV 3.1



EUROTRONIC®

Cada día más cerca de tí

www.eurotronic-europe.com

NOX CURTAIN



Motor para cortinas tradicionales con final de carrera electrónico y via radio.

Motor curtain electronic limit switches-radio.

Moteur pour rideaux traditionnel avec fin de course via radio.

Motore per tenda tradizionale con fine corsa elettronico e via radio.

AC 110- 230V 50/60HZ



NEUTRO
NEUTRAL
NEUTRE
NEUTRO




FASE
LIVE
PHASE
FASE




TIERRA
EARTH
TERRE
TIERRA

Instalación motor
Motor installation
Installation du moteur
Installazione motore



Desinstalación motor
Motor uninstalling
Désinstallation du moteur
Desinstallazione motore





Nuevo emisor
New transmitter
Nouvel émetteur
Nuovo trasmettitore

N




Emisor ya memorizado
Programmed transmitter
Émetteur programmé
Trasmettitore programmato

P




Three button control




Action	K1	K2	K3
◀▶ (Open)	on	off	off
▶◀ (Close)	off	on	off
■ (Stop)	off	off	on
Action time must less than 1 S			

Two button control



Action	K1	K2
◀▶ (Open)	on	off
▶◀ (Close)	off	on
■ (Stop)	Press any button again	


Hold on control



Action	K1	K2
◀▶ (Open)	on	off
▶◀ (Close)	off	on
■ (Stop)	off	off
Action time must continue		


METODO 1

Programación - Programming - Programmation - Programmazione




METODO 2


Programación - Programming - Programmation - Programmazione




Finales de carrera - Limit position - Fin de course - Impostazione fine corsa discesa




Cambio dirección - Change of direction - Changement de direction - Cambio di direzione



Añadir nuevo emisor - Add the new transmitter - Ajouter le nouvel émetteur - Aggiungere il nuovo trasmettitore



Reset del motor - Reset motor - Réinitialisation du moteur - Reset motore



www.eurotronic-europe.com