


REV 2.0






EUROTRONIC®

Cada día más cerca de tí


www.eurotronic-europe.com

NOX WR

Módulo internet
Internet module
Module internet
Dispositivo internet




- | | | |
|--|--|---|
| 1. Conector miniUSB (5VDC 1A)
Mini USB connector (5VDC 1A)
Connecteur mini (5VDC 1A)
Connettore miniUSB (5VDC 1A) | 3. Pulsador de instalación / RESET
Installation switch / RESET
Pulsateur d'installation / RESET
Pulsante di installazione / RESET | 5. Conector de antena RF 433Mh
Antenna connector RF 433Mh
Connecteur d'antenne RF 433Mh
Connettore antena RF 433Mh |
| 2. Conector de Red RJ45
Network connector RJ45
Connecteur réseau RJ45
Connettore di rete RJ45 | 4. Conector de antena RF 868Mh
Antenna connector RF 868Mh
Connecteur d'antenne RF 868Mh
Connettore antena RF 868Mh | |




- | | |
|----|--|
| L1 | (Verde – alimentación)
(Green – power supply)
(Vert – Alimentation)
(Verde – alimentazione) |
| L2 | (Naranja – tarea en proceso)
(Orange – task in process)
(Orange – Tâche en procès)
(Arancione – Lavorazione in corso) |
| L3 | (Rojo – sin acceso a servidor)
(Red – without access server)
(Rouge – sans accès au serveur)
(Rosso – nessun accesso alla rete) |
| L4 | (Azul – tareas de red)
(Blue – network tasks)
(Bleu – Tâches de réseau)
(Azzuro – rete attiva) |


Conexiones - Connections - Connexions - Collegamento



Aplicación - Application - Application - Applicazione - Emparejamiento



Emparejamiento - Synchronization - Synchronisation- Abbinamento



Instalar motor NOX/NOXON RM - Install NOX/NOXON RM motor
 Installer moteur NOX/NOXON RM - Installare motore NOX/NOXON RM



Configuración- Configure
 Configurer - Configura

eurotronic


Nombre nueva zona-Name new zone
 Dénomination de la nouvelle zone-Nome nuova zona



Añadir modulo- Add module
 Ajouter module-Aggiungi modulo

Modulo añadido-Module added
 Module ajouté-Modulo aggiunto

Instalar motor NOXON RE- Installer moteur NOXON RE- Installer moteur NOXON RE- Emparejamiento NOXON RE




Configuración- Configure
 Configurer - Configurare

eurotronic

Nueva zona -New zone
 Nouvelle zone - Nuova zona

Nombre nueva zona-Name new zone
 Dénomination de la nouvelle zone
 Nome nuova zona



Añadir modulo
 Add module
 Ajouter module
 Aggiungi modulo

Modulo añadido
 Module added
 Module ajouté
 Modulo aggiunto



Avda. Parc Tecnològic 3 Parc tecnològic del Vallès
08290 - Cerdanyola del Valles - Barcelona - España
+34 93.242.01.08 | www.eurotronic-europe.com